


Quickmate Instructions V1.0



1. This is what you need to start stretching




2. Place the canvas on both sides between the aluminium bars. Fasten it by firmly turning the knobs.



3. Whilst using the ratchet you stretch both sides of the canvas together and taught.



4. Staple the stretched canvas on both sides.



5. Loosen the knobs to remove the quickmate completely from the canvas. Next do the corners of the canvas.



6. Stretch the remaining two sides and staple.



7. The result? A nicely stretched canvas!.